



Building underlay over Apron flashing

Ultraclad® vertical weatherboards fixed with Locator Clips fixed at Max 600 mm vertical centres with 8g x 2" CSK Sq S/S self tapping screws through batten into dwang / nog

Ultraclad® Cavity Vent Strip Alternatively use PVC type

Note: Underlay strips to isolate aluminium from treated timber battens. Refer V00

Cavity batten Refer V00 Batten Options

Ultraclad® UA 4863 Board Starter B alternatively use UA 4862. 5 mm diameter drainage hole drilled through base of Vertical Starter at 300 mm centres

Apron flashing with 75 mm up stand cover behind cladding

Turn-down to suit roofing profile

Note: Ensure to alternate spacings of fixings for battens and Locator Clips to avoid risk of splitting batten

75 mm MIN cover above bottom of weatherboard  
110 MIN Total

35 MIN clear gap

10

Roofing underlay turned up under flashing

Selected roofing with stop ends

Flashing length See Table 7 E2/AS1

REVISION:	11
SCALE:	1 : 3 (@A4)
DATE:	2024
BRANZ APPRAISAL #796	