



KEY	
	Framing
	Batten
	Corner Batten
	Vertical Track Flashing

### Batten options

Impervious barrier ( MDPE ) or similar tape between cladding and batten.  
To comply with NZBC E2/AS1 - Table 23

Note:

Some machining of battens may be required to avoid "build up". i.e. back flashings / tapes

Cavity plastic Batten

Note: packing/shims may be needed to ensure boards are fitted flat without distortion.

\* Additional timber may be required at soffit to support UA 5831 Soffit Base.

### Note: Important

Underlay strips to isolate aluminium from treated timber battens 50 mm wide medium density polyethylene ( MDPE )

To comply with NZBC E2/AS1 - Table 23. Properties of roofing underlays and wall underlays, separates aluminium components and accessories from timber battens treated with copper-based treatments

Cavity closers required as per NZBC E2/AS1 (section 9.1.8)

Vertical Cavity Corner Batten  
50 x 25 mm H3.1 treated Radiata.  
Cavity battens fixed with 6g x 1.25" CSK Sq S/S pre-drilled screws through batten into stud

0.9 x 90 mm Aluminium Track Flashing.  
Alternatively use Dynex Dynafash

**ULTRA CLAD**  
Ultra-high performance cladding systems

PO Box 58009  
Botany  
Auckland 2163

Tel: 0800 500 338  
Email: buildingsystems@vulcan.co  
Web: buildingsystems.vulcan.co

**VULCAN.**  
© 2023 Vulcan. All rights reserved.

## V00 WALL BATTEN ELEVATION

Building Systems: Vertical Weatherboard Cavity System

REVISION:	12
SCALE:	1 : 20 (@A4)
DATE:	2024
BRANZ APPRAISAL #796	